

Mi Wireless Outdoor Security Camera 1080p

User Manual



Read this manual carefully before use, and retain it for future reference.

Precautions


- The operating temperature range for this camera is -20°C to 50°C. Do not use this camera in environments with temperatures higher or lower than the specified operating range.
- This camera is a precision electronic product that has an IP65 waterproof rating. Do not expose this camera to extremely humid environments or locations that are prone to water getting into the camera, to avoid affecting normal use.
- The outdoor camera contains a battery, do not expose it to direct sunlight, fire, or other heat sources.
- To improve the camera's performance, do not place its lens facing or next to reflective surfaces, such as glass windows or white walls, as this will cause the image to appear overly bright in areas close to the camera and darker in areas further away, or cause the camera to produce completely white images.
- Ensure that the camera is installed in an area with a strong Wi-Fi signal. Do not install the camera near microwave ovens, and other objects or places that affect its Wi-Fi signal.
- When the night vision function is enabled or disabled, the outdoor camera will switch the IR cut-off filter, which may be accompanied by a slight clicking sound, which is normal.
- Please do not disassemble or replace the outdoor camera's battery yourself. Improper operation may result in an explosion hazard.
- Use in a low temperature environment or while charging will affect the standby time of this product. Please do not use the real-time footage function for a long time while charging to avoid the loss of battery life. The actual standby time is related to the usage environment and habits.

Product Overview


Package Contents




Outdoor Camera
(Including Battery)



Mounting Template Sticker



Wall Plug × 3



Screw × 3



Charging Cable (1 m)



User Manual




Warranty Notice



Attention Sticker


Note: Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Outdoor Camera




Outdoor Camera Installation

1. Paste the mounting template sticker on the wall.
2. Drill two holes in the wall according to the positions of the holes on the mounting template sticker, the holes should have a diameter of about 5 mm and a depth of about 26 mm.
3. Install the wall plugs into the drilled holes.




4. As shown in the figure, remove the anti-theft screw from the base and push the camera up to remove it from the base mounting plate.




5. Install the base mounting plate on the wall with the screw.

Note: The anti-theft screw hole should face downwards.



6. Keep the button of the outdoor camera facing downwards and rotate the base of the outdoor camera 180° so that the anti-theft screw hole faces downwards.

7. Install the outdoor camera on the base mounting plate and tighten the anti-theft screw.



How to Use

Charging: Please fully charge the outdoor camera before using it.

Turning on/off: Press the power button to turn on/off the outdoor camera.

Resetting: When turned on, press and hold the power button for 5 seconds, and the indicator will blink orange once the outdoor camera has been reset successfully.

Indicator Status Description

Awaiting reset: Orange

Connecting: Blinking blue

Charging: Blinking red

Awaiting connection: Blinking orange

Connected: Off

Fully charged: Off

Connecting with Mi Home/Xiaomi Home App

- This product works with the Mi Home/Xiaomi Home app*. Use the Mi Home/Xiaomi Home app to control your device, and to interact with other smart home devices.
- Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search "Mi Home/Xiaomi Home" in the app store to download and install it.
- Make sure that an indoor receiver compatible with this outdoor camera has been purchased and installed separately, and that the indoor receiver has been connected to the app successfully.



- Open the home page of the Mi Home app, tap the + icon in the top right corner, scan the QR code of the outdoor camera body, and complete the pairing by following the instructions in the app. The indicator will turn off after pairing successfully.

Note:

- This product only supports connecting to a 2.4 GHz Wi-Fi network, and does not support 5 GHz Wi-Fi networks. The indoor receiver can also be connected with an Ethernet cable.
- The version of the app might have been updated, please follow the instructions based on the current app version.

Specifications

Name: Mi Wireless Outdoor Security Camera 1080p

Model: MWC14

Rated Input: 5 V= 2 A

Outdoor Camera Dimensions: 52.7 × 122 × 102.6 mm

Outdoor Camera Net Weight: 273 g

Lens Angle: 130°

Resolution: 1920 × 1080

Aperture: F2.1

Video Codec: H.265

Night Vision Light: Eight 940 nm IR Lights

Operating Temperature: -20°C to 50°C

IP Rating: IP65

Battery Capacity: 5700 mAh 3.65 V

Wireless Connectivity: Wi-Fi IEEE 802.11 b/g/n 2.4 GHz

Compatible with: Android 6.0 & iOS 10 or above

Wi-Fi Operation Frequency: 2412–2472 MHz

Wi-Fi Maximum Output Power: <20 dBm

Battery Safety

This device is equipped with a built-in battery that cannot be removed or replaced. Do not disassemble or modify the battery by yourself.

WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

CE Information



Hereby, Shanghai Moshon Technology Co., Ltd. declares that the radio equipment type MWC14 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.mi.com/global/service/support/declaration.html>

Manufactured for: Xiaomi Communications Co., Ltd.
Manufactured by: Shanghai Moshon Technology Co., Ltd.
Address: No. 668 Xinzhuan Road, Songjiang Hi-Tech Park,
Caohejing Development Zone, Shanghai, China
For further information, please go to www.mi.com
User Manual Version: V1.0

Importer:
Beryko s.r.o.
Na Roudné 1162/76, 301 00 Plzeň
www.beryko.cz