

For further information, please go to [www.mi.com](http://www.mi.com)  
For detailed e-manual, please go to [www.mi.com/global/service/userguide](http://www.mi.com/global/service/userguide)

## Xiaomi Electric Scooter 4 Go User Manual

Read this manual carefully before use, and retain it for future reference.

Importer:  
Beryko s.r.o.  
Pod Vinicemi 931/2, 301 00 Plzeň  
[www.beryko.cz](http://www.beryko.cz)

Original instructions




CE.04.00.0786.00-E





## Product Overview



① Handlebar

② Front Light

③ Scooter Bell

④ Brake Lever

⑤ Stem

⑥ Reflector

⑦ Front Fork

⑧ Wheel Motor

⑨ Charging Port

⑩ Accelerator

⑪ Control Panel & Power Button

⑫ Bell Lever

⑬ Quick-release Clamp

⑭ Clamp Nut

⑮ Mudguard

⑯ Taillight

⑰ Drum Brake


⑱ Side Reflector

⑲ Kickstand

⑳ Battery Compartment



## Control Panel & Power Button



① **Speedometer:** Display the current speed of the scooter, as well as to display error codes.

② **Bluetooth:** When this icon lights up, it indicates that the scooter has been successfully connected to the mobile device.

③ **Temperature Warning:**

- When the scooter is not being charged, if the ambient temperature is lower than  $-10^{\circ}\text{C}$  or higher than  $45^{\circ}\text{C}$ , the temperature error icon on the control panel will blink. Riding in such circumstances may result in reduced performance of the scooter and other risks. You can use the scooter after the temperature returns to the normal operating range.
- When the scooter is being charged, if the ambient temperature becomes lower than  $0^{\circ}\text{C}$  or higher than  $40^{\circ}\text{C}$ , the temperature error icon on the control panel will blink and the scooter may become unable to be charged. Continuing charging the scooter may even pose a risk. When the ambient temperature returns to the range of  $0^{\circ}\text{C}$  to  $40^{\circ}\text{C}$ , the temperature error icon will go out and you can charge the scooter again.

④ **Control Panel & Power Button:** Press the button to turn the scooter on, and hold the button for 3 seconds to turn the scooter off. When the scooter is on, press the button to turn on/off the headlight and taillight, and press twice to cycle through the modes.

⑤ **Modes:**  $\text{A}$  is for pedestrian mode; the maximum speed of the scooter is 6 km/h, and the taillight is blinking in this mode. D is for standard mode, and S for sport mode.



⑥ **Locking Reminder:** When the icon lights up, it indicates that the scooter is locked. You can lock/unlock the scooter via the Mi Home/Xiaomi Home app.

⑦ **Error Notification:** When the wrench icon displays red, it indicates that the scooter needs repair. When the wrench icon blinks red, it indicates that the scooter has an error.

⑧ **Battery Level:** The battery power is indicated by 5 bars, each representing approximately 20% of a full battery.



## Package Contents



Battery Charger



User Manual




Specifications and Certifications




Important Information




## Assembly and Set-up




- 1 Hold the stem and the middle of the deck to place the scooter on the ground. Then put down the kickstand.



- 2 Lift the stem up, and open the quick-release clamp. Align the stem with the groove and install it onto the front fork assembly.



- 3 Secure the quick-release clamp firmly after the spring button pops out.




- 4 Shake the stem before riding to make sure the quick-release clamp is secured.

## Adjusting the Quick-release Clamp


### Clamp Nut

Turn the nut on the quick-release clamp counterclockwise or clockwise to loosen or tighten the clamp.



## Charge Your Scooter


The scooter is fully charged when the LED on the charger changes from red (float charging) to green (trickle charging).



When the battery level is under 30% and the scooter is not powered on for about 10 consecutive days, the battery will enter into sleep mode. If this happens, your scooter cannot be powered on. Please charge it for three seconds to activate the battery.



## Connect with Mi Home/Xiaomi Home app



Before being activated, the scooter will keep beeping when turned on and is limited to 10 km/h. Once the scooter is activated, the beeping alarm will stop and the speed restriction will be lifted.

Note: The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.




1 Scan the QR code to download and install the app.



2 Open the Mi Home/Xiaomi Home app.




3 Tap "+" on the top right corner, and then select "Add a device" or "Scan".



4 Follow the instructions to add and pair the scooter. Note: The QR code attached on the control panel is unique to your scooter, please keep this code safe.

Note: The version of the app might have been updated, please follow the instructions based on the current app version.



- 5 Watch the tutorial for beginners to activate the scooter.  
Note: Do not exit the tutorial before finishing it. Otherwise, the activation will fail.




## How to Ride




- 1 Warning: Wear a helmet, elbow pads and knee pads.  
Note: Please check the tire pressure before riding.




- 2 Step on the deck with one foot, and slowly kicks off the other on the ground.




- 3 The accelerator initiates once the coasting speed exceeds 5 km/h.



- 5 Tilt your body to the steering direction as you turn, and slowly turn the handlebar.




- 4 Release the accelerator and squeeze the brake lever for a sudden brake.



- 6 Put down the kickstand when parking.




## Safety Reminder




Always steer clear of obstacles.


## Watch out for safety risks




Avoid hitting your head on door frames, elevators, and other overhead obstacles.



Do not press the accelerator when you are walking alongside the scooter.




Unless otherwise authorized by the local laws, it is forbidden and illegal to ride on public roads, motorways, and expressways.




Do not abruptly change the steering direction at high speed.

## Do not try dangerous actions





Do not hang bags or other heavy stuff on the handlebar.





Do not ride on one foot.








 Do not accelerate when going downhill, and brake in time to slow down. When on a steep slope, you need to step off the scooter and push.




 Do not use mobile phone or wear earphones when operating the scooter.




 Do not keep your feet on the rear mudguard.





 Do not touch the drum brake.

### Do not try dangerous actions




 Do not ride in the rain. Do not ride through puddles or any other (water) obstacles.





 Do not ride with anyone else, including children.

### Do not try dangerous actions



 Do not let go of the handlebar while riding.




 Do not try riding up or down stairs, nor try jumping over obstacles.




## Carry Your Scooter

Note: This scooter cannot be folded. Please uninstall the stem before carrying the scooter.




- 1 Put down the kickstand, and open the quick-release clamp.



- 2 Press the spring button and lift up the stem.

- 3 Flip up the kickstand, and simultaneously hold the stem and the middle of the deck to carry the scooter.





## Lock & Unlock Your Scooter




Image 1 Tap Lock the motor

Locking the Scooter: Tap Lock the motor in the Mi Home/Xiaomi Home app to lock the scooter as illustrated in Image 1. When the scooter is locked, the motor is locked and all the icons on the control panel will automatically go out except the Bluetooth icon and the lock icon. If the scooter goes beyond the Bluetooth connection range, the Bluetooth will be disconnected and its icon will go out.




Image 2 Motor locked

Motor Locked: After the motor is locked as illustrated in Image 2, the front wheel of the scooter cannot move normally. The control panel will sound an alarm when someone forcibly pushes the scooter.




Image 3 Tap Unlock the motor

Unlocking the Scooter: Tap Unlock the motor in the Mi Home/Xiaomi Home app to unlock the scooter as illustrated in Image 3.

Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.